

BrakeTime Tire Installation Guide

Schedule your appointment online or call 216-202-4343.

Sorry, but we cannot install run-flat tires.

This price does not include tire disposal fees or any applicable state environmental taxes.

Basic installation package

- Tire mounting
- Valve stem/TPMS^[1] service pack
- 50-mile lug re-torque
- Additional \$10 per tire fee for tires not purchased from BrakeTime
\$15 per tire

Value installation package

- Basic package
- Road hazard protection warranty^[2] (Available only for tires purchased from BrakeTime)
\$25 per tire

Prices for tire service if tires were not purchased from BrakeTime

Lifetime balance & rotation

\$12 per tire

Valve stem/TPMS service pack

\$3 per tire

Flat tire repair (tubeless)

\$12 per tire

Tire mounting (carry-in)

\$10 per tire

Tire mounting (specialty)

\$5 per tire

Tire rotation

\$2.50 per tire

Lug nut replacement

\$2 per lug nut (Cost can vary depending on the vehicle)

Additional Information

1. Tire Pressure Monitoring Systems (TPMS) continuously check tire pressure and display the information for the driver. [↗](#)
2. The road hazard protection warranty provides coverage for tire failure caused by impact breaks and other non-repairable punctures. We will fix repairable punctures at no charge. For conditions that require replacing the tire, please ask. [↗](#)